

Cistern lever should be installed on the right of the cistern for LH installation and on the left for a RH installation. (Left hand illustrated.)

There must be visual contrast between the wall and floor finishes.

The wall finish must also contrast with the sanitaryware and grab rails. Lever action tap supplied.

The basin must be handed left and right to enable the tap to be fitted nearest to the W.C. Failure to achieve this will render the installation non-compliant. Doors should be fitted with light action privacy bolts with emergency release mechanisms or N&C Phlexicare Radar locks supplied by N&C under the Radar National key scheme.

All doors, alarms, Equality Act compliant handles & associated Ironmongery can all be obtained from N&C.

An emergency assistance alarm must have:

- 1. Visual and audible indicators confirming the emergency call has been received.
- 2. A reset control reachable from the W.C. pan or a wheelchair shower seat.
- 3. A signal that is distinguishable visually and audibly from the fire alarm.
- 4. A red alarm cord with two rings, one set between 800mm and 1000mm and the other 100mm above the floor surface.

White Economy Low Level			P6830063	
1	BSS Low Level Raised Height Pan	3	Concealed Basin Hangers - Pair	
1	White Seat, no Cover	3	Chrome Spray Mixer Tap - Lever Operation	
2	Pentland Reversible Cistern	3	Chrome 32mm Grated Waste	
2	6 litre Cistern Fitting Pack	4	White Single Folding Rail 750mm	
2	Chrome Spatulate Flush lever	5	White Backrest Rail 400 x 250mm	
2	White Flushbend 760 x 305mm	6	White ABS 600 x 35mm Grab Rails x 5	
3	Pentland Hand Basin 395 x 340 mm			
3	White Plastic Taphole Stopper	For accessories see page 247.		

Blue Economy Low Level			P6830064	
1	BSS Low Level Raised Height Pan	3	Concealed Basin Hanger Brackets - Pair	
1	Blue Seat (Advanced) no Cover	3	Chrome Spray Mixer Tap - Lever Operation	
2	6 litre Cistern Fitting Pack	3	Chrome 32mm Grated Waste	
2	Chrome Plated Spatulate Flush Lever	4	Blue Twin Folding Rail 750mm	
2	Pentland Reversible Cistern	5	Blue Backrest Rail 400 x 250mm	
2	White Flush Bend 760 x 305mm	6	Blue Fluted 600 x 35mm Grab Rails x 5	
3	Pentland Hand Basin 395 x 340mm			
3	White Plastic Taphole Stopper	For accessories see page 247.		