



The shower room must have a 2100mm minimum unrestricted height.

The floor of the shower area and shower room must be slip resistant and self draining.

A shelf reachable from the shower seat or wheelchair before or after transfer must be provided for toiletries.

A shower fixing should be controlled by a lever operated thermostatic mixer that delivers water at a temperature not exceeding 43 degrees. The markings on the shower control should be logical and clear to blind and partially sighted people.

The temperature of the water circulating in the pipework needs to be at least 60 degrees to avoid the risks of legionella.



The basin in the bathroom is large enough for hair or full body washing, it can be used for hand rinsing. It is likely that users will fill the basin with water before sitting on the W.C. pan, as the tap may be out of reach.

For the complete W.C. portion of this package please specify P6830070

For the complete showering portion of this package please specify P6830065

Blue Shower room

P6830065

1	Grey Folding Shower Seat
2	Grey Backrest for Shower Seat
3	Blue Fluted 600 x 35mm Grab Rails x 3
4	Blue Rehab 850mm Folding Rails x 2
5	Additional Phlexicall Alarm Pull Cord
6	Chrome Thermostatic Shower Valve TMV3
6	Chrome Shower Head and Kit

7	Chrome Curtain Rail 1170mm x 2
7	Chrome Wall Flanges - Pair
7	Chrome Angle Bend
7	Ceiling Support Stay 455mm
7	Weighted Shower Curtains 2135 x 2135mm x 2
7	Shower Curtain Hooks x 3
8	Robe Hooks
9	Large Shelf

Blue WC/Shower room Low Level

P6830070

1	Pentland Back to Wall Low Level Raised Height Pan
1	Blue Seat (Advanced) no Cover
2	Pentland Reversible Cistern with Screw Down Lid
2	6 litre Cistern Fitting Pack
2	Chrome Plated Spatulate Flush Lever
2	White 760 x 305mm Flushbend
3	Pentland Wash Hand Basin 550 x 450mm
3	Hanger and Waste Bracket
3	Chrome Thermostatic Mono Basin Mixer - Lever Operation
3	Chrome Presflo Waste
3	Chrome 32mm Plastic Bottle Trap
4	Phlexicall Audio Visual Alarm with Reset

5	White Plastic Colostomy Bag Shelf, Small
14	White Plastic Colostomy Bag Shelf, Large
6	Toilet Tissue Dispenser
7	Paper Towel Dispenser
8	Soap Dispenser
9	Automatic Hand Dryer
10	Stainless Steel Mirror 1000 x 400mm
11	Blue Fluted 600 x 35mm Grab Rails x 5
12	Blue Rehab 850mm Folding Rail
13	Blue Clothes Hooks x 2